

Foot Pedal Replacement Instructions

Follow instructions provided to ensure safety. Consult personal or company procedures as needed. Contact 911 Blasters with questions or concerns at 251-580-8537 or by email at office@911blasters.com.

1) Turn off pump and light power switches. Disconnect the GFCI from the outlet.



2) Turn off the air supply to the air line if able. Disconnect the air line from the foot pedal.



3) Cut the hose connecting the cabinet to the old foot pedal just above the fitting.



4) Crimp the o-clamp around the new hose ensuring a tight fit. It is best to use o-clamp pliers shown.

